



## ASSEMBLY INSTRUCTIONS

1. SLIDE UPPER ARM WITH MOUNTING BRACKET FACING INWARD OVER STAND BASE UNTIL DETENT PIN POPS THROUGH DETENT PIN HOLE AS IN FIG A.
2. REPEAT STEP ONE WITH OPPOSITE ARM.
3. ATTACH WHEEL ASSEMBLY TO STAND AS IN FIG C.
4. ATTACH SHREDDER TO ASSEMBLED STAND WITH THE TIMER UP AS IN FIG B. WITH PROVIDED 1/2" BOLTS. (DO NOT OVER TIGHTEN OR SHREDDER WILL NOT ROTATE.)

