


Start

Before starting the machine, please confirm that:

- The equipment is firm and the wiring is correct.
- The safety guard has been installed correctly.
- Any installation remains that can be inhaled by the fan have been removed, and the pipeline connected to the fan has been cleaned up.
- The ground wire is properly connected.
- The electrical safety device has been correctly connected and adjusted to the proper position.

Disassembly Size



UNIT:mm

Model	A	B	D	La	Wa
DF100-M/A	166	300	□98	81	60
DF150-M/A	200	315	□148	81	60
DF200-M/A	235	310	□198	102	80

Warranty Card


Seller shop address or website

Model

Warranty reacon

Date or purchase

Sell establishment seal



Duct Fan Instructions