

1. Unplug machine

- 2. Insert basket into barrel over the mounting bolts and twist basket.
- 3. Tighten the 4 bolts.

