



Operating Instructions

- 1. Remove position pin and rotate barrel upright.
- 2. Fill material housing with product.
- 3. Replace safety lid and position pin.
- 4. Plug in machine.
- 5. On timer, during stand by mode, press SET and "0" will be shown on the display.
- 6. Modify the time interval with the "up" and "down" keys.
- 7. Press "SET" to enter time, and machine will start.
- 8. Remove Tray and empty into desired container
- 9. Remove sifted material from basket.
- 10. Repeat steps 2-9

Maintenance

Periodically blow out motor and material housing with air.

Use ammonia free cleaner on safety lid.

Clean material housing with alcohol before storage.