


Zoom Pro Assembly Instruction Sheet

- 1 Remove all 4 crate sides and packing
- 2 Remove hoses, wheels under frame, hopper and jack handle
- 3 Unbolt jack foot pad, axles straps and remove all 4 axle clips and washers
- 4 Install jack handle on post with bolt and nut
- 5 Raise machine with jack and install wheels - all washers go on the side next to wheel axle clip
- 6 Raise opposite side of machine and install the other 2 wheels, washers and axle clips
- 7 Carefully move machine off wood crate base
- 8 Check to make sure all guards are in place and fully latched
- 9 Refer to the instruction manual for machine operation and startup

Please note:

Machine adjustment may change during shipping - make sure to follow the following 2 steps

With machine removed from crate and unplugged.

- * **Barrels** - The barrels should rotate freely turning by hand with belt on and make no metal scraping noises on blades, guards, and reel cutter.
- * **Reel Cutter** - Turn reel motor v-belt pulley under belt guard by hand and make sure it turns freely and there is no reel contact with the stationary blades or barrels  **NO POWER** is connected.

Refer to the manual for blade and barrel adjustment

Vacuum System

Follow assembly directions inside vacuum box

Wheel axle clip installation & removal

