





ZEPHYR 1

Day/Night Thermostat
Easy Guide




Note: This unit has been set to perform cooling function.
For heating function, refer to Optional settings.

INSTRUCTIONS – REV. A




Step 1
Set values for Day and Night temperatures




Step 2
Plug into 120VAC outlet
Place the sensor at desired location
Connect the heating or cooling element in the front panel outlet
Installation is now complete

OPTIONAL SETTINGS



Change to heating
A. Set both values to minimum
B. Plug in, then set both values to maximum within 5 seconds
C. Output light turns on
D. Follow instructions as shown in Step 1 & 2



Change to cooling
A. Set both values to maximum
B. Plug in, then set both values to minimum within 5 seconds
C. Output light turns on
D. Follow instructions as shown in Step 1 & 2

Sunlight Supply, Inc.
National Garden Wholesale
VANCOUVER, WASHINGTON U.S.A.



www.titancontrols.net

For technical assistance call us at
1-888-80-Titan or 1-888-808-4826.